



Table of Contents

lippert.com

Introduction	1
Safety Information	1
Parts List	2
Resources Required	3
Prior to Installation	3
Installation	3
Fixed Faucet	3
Pull Down Faucet	4
Operation	5
Fixed Faucet	5
Pull Down Faucet	6
Troubleshooting Chart	7
Maintenance	7
Notes	8

Flow Max[™] Faucets

Installation and Owner's Manual

(For Aftermarket Applications)

Introduction

Add a splash of modern to your kitchen or bath with a Flow Max Faucet by Lippert. Available in a variety of spout constructions, including coiled spring and high-arched, we are challenging how the world feels about faucets. Constructed with quality stainless steel, black matte finish and satin bronze, these sleek faucets are designed for maximum lifespan and durability.

Safety Information

A CAUTION

THE "CAUTION" SYMBOL ABOVE IS A SIGN THAT
A SAFETY RISK IS INVOLVED AND MAY CAUSE
PERSONAL INJURY AND/OR PRODUCT OR PROPERTY
DAMAGE IF NOT SAFELY ADHERED TO AND WITHIN
THE PARAMETERS SET FORTH IN THIS MANUAL

A CAUTION

MOVING PARTS CAN PINCH, CRUSH OR CUT. KEEP CLEAR AND USE CAUTION.

A CAUTION

UNIT MUST BE WINTERIZED PER MANUFACTURER'S RECOMMENDATIONS. FAILURE TO WINTERIZE THE UNIT COULD DAMAGE THE FAUCETS AND OTHER PLUMBING SYSTEM COMPONENTS.



Installation and Owner's Manual

(For Aftermarket Applications)

Parts List



719323 Spring Faucet Coil Spring Installation Black matte 2021090598

2022007782

Waterfall Bathroom Fixed



719324 Curved Gooseneck Fixed Installation Black matte 2021090601



2022109922 Coil Spring Faucet Stainless Steel/Black matte



2024000071 **Bullet Pull Down Installation** Black matte/Satin Bronze



2024000066 Square Gooseneck Satin Bronze

2



719333 **Bullet Pull Down** Pull Down Installation Black matte 2021090600



719325 Square Gooseneck Fixed Installation Black matte 2021090597

Part #	Description	
Stainless Steel Finish		
<u>719323</u>	Coil Spring Faucet, Single Hole	
<u>719324</u>	Curved Gooseneck Faucet, Single Hole	
<u>719325</u>	Square Gooseneck Faucet, Single Hole	
<u>719333</u>	Bullet Pull Down Faucet, Single Hole	
2022007782	Waterfall Bathroom Faucet, Single Hole	
Black Matte Finish		
2021090598	Coil Spring Faucet, Single Hole	
2021090601	Curved Gooseneck Faucet, Single Hole	
2021090597	Square Gooseneck Faucet, Single Hole	
2021090600	Bullet Pull Down Faucet, Single Hole	
2021090599	Waterfall Bathroom Faucet, Single Hole	
Stainless Steel/Black Matte Finish		
2022109922	Coil Spring Faucet, Single Hole	
Satin Bronze Finish		
2024000071	Bullet Pulldown Faucet - Black Matte/Satin Bronze	
2024000066	Square Gooseneck Faucet- Satin Bronze	

If your faucet is obsolete or not shown in this manual, there are numerous documents to assist with troubleshooting. Please visit support.lci1.com/kitchen.



Installation and Owner's Manual

(For Aftermarket Applications)

Resources Required

- · Phillips screw driver
- · Adjustable wrenches
- Bucket
- Flashlight
- · Safety glasses

Prior to Installation

- **1.** Shut off the hot and cold water outlet supply valves for the existing faucet, typically located below the sink.
- **2.** Relieve any pressure from the existing faucet by turning the existing faucet on and off.
- **3.** Place a bucket under the sink, under the supply lines' supply valves to catch any excess water.
- **4.** Using an adjustable wrench, disconnect the supply lines from the outlet water supply valves. Place the supply lines into the bucket to drain any excess water.
- **5.** Under the sink, disconnect the mounting hardware for the existing faucet and remove the faucet from the deck.
- **6.** Make sure the deck around the mounting hole area is clean, dry and free from any debris.

Installation

Fixed Faucet

- **1.** Unscrew the metal collar with the two screws from the faucet base and set aside (**Fig.1A**).
- **2.** Remove the metal washer **(Fig.1B)** from the base and set aside.

NOTE: Leave black rubber washer (Fig.1C) on faucet.




Fig.1

- **3.** Place the faucet supply lines through the mounting hole on the deck, making sure the black rubber washer and faucet base are seated firmly on the deck of the sink (**Fig.2A**).
- **4.** Position the faucet base so the handle is to the right side of the faucet base (**Fig.2B**).

NOTE: The handle can be positioned to the left of the faucet base but is typically placed to the right. Placing the handle in the middle may cause severe burns depending on where the faucet neck is located when turning on the water.





Fig.2

5. Under the sink, slide the metal washer (**Fig. 1B**) over the supply lines onto the base of the faucet. Make sure the metal washer is flush against the underside of the sink deck and covering the mounting hole (**Fig.3A**).





Installation and Owner's Manual

(For Aftermarket Applications)

6. Make sure the two screws on the collar are evenly inserted and are flushed with the top of the collar **(Fig.4A)**.



Fig.4

7. Screw the collar onto the faucet base all the way up to the metal washer **(Fig.5A)**.

NOTE: Make sure the handle of the faucet is placed in the desired position.

8. Using a Phillips screwdriver, tighten the two screws (**Fig.5B**) on the collar to hold the collar into place.




Fig.5

NOTE: The red-marked supply line is for hot water and the blue-marked supply line is for the cold water.

- **9.** Thread the nut on the hot water supply line onto the hot water outlet supply valve and tighten with an adjustable wrench. Do not over tighten.
- **10.** Thread the nut on the cold water supply line onto the cold water outlet supply valve and tighten with an adjustable wrench. Do not over tighten.
- **11.** Turn the hot and cold water outlet supply valves back on and check for any leaks.

Pull Down Faucet

1. Unscrew the black plastic coupler from the faucet base and slide off from the faucet assembly.

NOTE: Wiggle the plastic collar off the supply lines one line at a time.

- 2. Slide the clear plastic washer off the faucet assembly.
- **3.** Place the faucet supply lines through the mounting hole on the deck, making sure the black rubber washer and faucet base are seated firmly on the deck of the sink (**Fig.6A**).





Fig.6

4

4. Under the sink, slide the clear plastic washer over the supply lines up to the underside of the sink deck and covering the mounting hole (**Fig.7A**).





Installation and Owner's Manual

(For Aftermarket Applications)

5. Slide the black plastic collar back onto the supply lines, inserting one supply line at a time.

NOTE: Make sure the inside threads of the black plastic coupler are at the top.

6. Screw the black plastic collar all the way up the faucet base until it will no longer turn (Fig.8A).




Fig.8

NOTE: The red marked supply line is for hot water and the blue marked supply line is for the cold water.

- 7. Thread the nut on the hot water supply line onto the hot water outlet supply valve and tighten with an adjustable wrench. Do not over tighten.
- 8. Thread the nut on the cold water supply line onto the cold water outlet supply valve and tighten with an adjustable wrench. Do not over tighten.
- 9. Turn the hot and cold water outlet supply valves back on and check for any leaks.

Operation

Fixed Faucet

1. Pull the lever away from the faucet to turn it on (Fig.9A).




Fig.9

5

2. Move the lever towards you for hot water (Fig. 10) and away from you for cold water (Fig. 11).

NOTE: Located on the front of the lever is a "H" for hot water and a "C" for cold water. Move the lever in the direction of the desired temperature.





Installation and Owner's Manual

(For Aftermarket Applications)

3. Push the lever in towards the faucet to shut the water off **(Fig.12A)**.




Fig.12

Pull Down Faucet

1. Pull the lever away from the faucet to turn it on (Fig.13A).





Fig.13

2. Move the lever towards you for hot water (Fig.14) and away from you for cold water (Fig.15).

NOTE: Located on the front of the lever is a "H" for hot water and a "C" for cold water. Move the lever in the direction of the desired temperature.



- **3.** To use the spray wand pull down and out on the faucet head.
- **4.** Press and release the button in on the lower portion of the faucet head **(Fig.16A)** for spray mode. Press and release the button again for stream mode.



Fig.16

5. Replace the faucet head by gently guiding the hose back into the faucet neck and insert into clip, if applicable.



Installation and Owner's Manual

(For Aftermarket Applications)

6. To shut the water off push the lever in towards the faucet (**Fig.17**).




Fig.17

Maintenance

- 1. Clean the faucet periodically.
- 2. Apply a coat of toothpaste to a wet soft-bristle toothbrush.

NOTE: Avoid abrasive cleaners, steel wool and chemical solutions as these will dull the finish and void the warranty.

- 3. Brush over the surface of the faucet.
- **4.** After cleaning, rinse the faucet thoroughly with water, washing away all the remains of the paste.
- **5.** Rub dry with a soft cloth.

A CAUTION

UNIT MUST BE WINTERIZED PER MANUFACTURER'S RECOMMENDATIONS. FAILURE TO WINTERIZE THE UNIT COULD DAMAGE THE FAUCETS AND OTHER PLUMBING SYSTEM COMPONENTS.

Troubleshooting Chart

Vibration caused by driving or transporting can loosen plumbing and hardware. Check for loose system components. Many symptoms can be resolved by tightening hardware. Use care not to over-tighten. Refer to the chart for troubleshooting tips.

What is happening?	Why?	What should be done?
Irregular Flow Blockage at the aerator. Cartridge is clogger		For further instructions reference: <u>TI-400 Flow Max Faucets Low Water Flow Troubleshooting</u>
	Cartridge is clogged.	For further instructions reference: <u>TI-394 Flow Max Faucet Cartridge Replacement</u>
There is a leak from the aerator when the faucet is on.	The aerator does not fit correctly on the faucet.	Remove aerator and re-install.
The aerator has irregular or reduced water flow.	The aerator is dirty.	Remove aerator and clear debris.

If your faucet is obsolete or not shown in this manual, there are numerous documents to assist with troubleshooting. Please visit support.lci1.com/kitchen.



Flow Max[™] Faucets

Installation and Owner's Manual

(For Aftermarket Applications)

Notes	
	<i>L</i> iPPERT [™]
	LIPPERI
	Manual information may be distributed as a complete
	document only, unless Lippert Components provides explicit consent to distribute individual parts.
	All manual information is subject to change without notice.
	Revised editions will be available for free download at lippert.com . Manual information is considered factual until made obsolete by a revised version.
	Please recycle all obsolete materials and contact
	Lippert Components with concerns or questions.
	1

8