



**BETTER BATH® CWS
MULTI-PIECE SURROUND
OEM INSTALLATION MANUAL**

L I P P E R T
C O M P O N E N T S®

Safety Information

LCI recommends that installations only be done by a qualified technician. LCI also recommends that the technician should use appropriate personal protective equipment, such as safety glasses and gloves, during the installation process.



Failure to follow the instructions provided in this manual may result in injury, component damage, or voiding of the component warranty.

Installation

NOTE: All caulks, adhesives, sealants **MUST** be compatible with ABS.

1. Wall area where CWS surround is placed and CWS surround **MUST** both be clean and dry. Ensure wall area is free of any protruding objects (nails, staples, etc.)
2. Cover tub/shower pan to protect surface and minimize cleanup.
3. Measure up from the deck of the tub 57" for a tub surround and 67" for a shower pan surround. Apply a ¼" bead of adhesive in a vertical or horizontal direction along or on top of each grout line, thus creating a grid on the wall where the surround will be adhered.

NOTE: If using spray adhesive, coat both the alcove wall and wall surround - see product instructions.

4. Side Panels: Set bottom of panel on deck of tub/shower pan and align edge of tile with front apron flange of tub/shower pan. Starting from the bottom of the panel, firmly press from center to edges and work upward. Pull panel away from wall, reposition and repeat installation.
5. Back Panels: Set bottom of panel on deck of tub/shower pan and center panel between tub/shower pan flanges. Firmly press from center to edges starting from bottom of panel. Pull panel away from wall, reposition and repeat installation.

NOTE: Use roller on side and back panels to remove all air and to ensure complete contact of adhesive.

6. RWS Surrounds Only: At this time drill oversized hole for rivet. Apply small amount of caulk on hole. Insert rivet and lightly tap drive pin until flush with rivet head.
7. Corner Caddy Installation: (Note: 3232 Shower Surround utilizes shower cove instead of caddies).
 - A. Wall panel **MUST** be clean and dry.
 - B. To ensure proper fit, test fit the caddy prior to installation.
 - C. Apply ¼" bead of adhesive strategically on back of caddy.
 - D. Remove paper from self-adhesive strips on caddy edges.
 - E. Ensure that contact area of surround panels is clean and free of dust & dirt before adhering the corner caddies.
 - F. Place squarely in corner with bottom of caddy sitting firmly on tub deck.
 - G. Press firmly creating solid bond to wall surround panels.
8. After tub/shower pan and surround have been cleaned and free of dust, ensure that installation is watertight.

Care and Cleaning Instructions

LCI Thermoforming units are easy to keep clean and sparkling. Simply use warm water and a mild soap solution. Rub with a soft cloth and rinse thoroughly with warm water. Do not use abrasive cleaners or harsh chemicals.

Recommended Cleaners: Mild soap and water, Fantastic Spray Cleaner, Top Job Liquid (3% solution), Spic and Span Pine Cleaner, Joy Liquid Detergent (5% solution), Gel-Gloss, "The Works" Tub and Shower Cleaner, DuPont 7 Auto "Polish," and DuPont 606S Auto "Polish." All cleaning should be followed by a warm water rinse.

Do Not Use: Disinfectant sprays, disinfectant foams, pine oil cleaners, citrus-based cleaners, abrasive cleaners, harsh chemicals, Scrubbing Bubbles, petroleum-based products, auto rubbing compounds or industrial or commercial cleaners.



If any adverse chemicals, as described in the Care and Cleaning Instructions, come in contact with any surface, immediately rinse thoroughly with clean water.

With the exception of Permalux® and Permalux Plus® products, fading or discoloration may result from continued exposure to direct sunlight. Keep blinds or drapes closed during periods of the day when the product is exposed to direct sunlight.

Do not place any hot objects or objects such as candles or cigarettes on the surface of this product. These objects may scar, burn or ignite this plastic.



L I P P E R T C O M P O N E N T S™

The contents of this manual are proprietary and copyright protected by Lippert Components, Inc. ("LCI"). LCI prohibits the copying or dissemination of portions of this manual unless prior written consent from an authorized LCI representative has been provided. Any unauthorized use shall void any applicable warranty. The information contained in this manual is subject to change without notice and at the sole discretion of LCI.

Revised editions are available for free download from lci1.com.

Please recycle all obsolete materials.

For all concerns or questions, please contact
Lippert Components, Inc.

Ph: (574) 537-8900 | Web: lci1.com | Email: customerservice@lci1.com