



1.877.287.8634

INSTALLATION INSTRUCTIONS

IMPORTANT NOTICE: Be sure to inspect and test fit product before having it coated or painted. Ranch Hand will not be responsible for the cost of the coating if any problems with fit or finish are not noted and addressed beforehand.

2018 - up FORD EXPEDITION GRILL GUARDS

PART # GGF19HBL1 / GGF19HBL1C

1. Remove the two plastic inserts located at the bottom of the bumper. *On 4x4s, remove the tow hooks.*



2. On the bottom of the frame rails, there will be two holes. Slide the tab with ½" nuts into the frame and over the holes. *On 4x4s, reuse the factory nut tabs located inside the frame.*



3. Mount the bottom brackets to the bottom of the frame. Use ½" bolts, lock washers and washers to install. Set the brackets to the distance of 39 5/8" or a little less. *On 4x4s, mount the tow hook, bottom bracket to the frame. Reuse factory bolts.* Hand tighten bolts.
4. Mount the grill guard to the outside of the bottom brackets with black Carriage bolts. Line up the grill guard from side to side then tighten the bottom bolts to the frame.
5. Line up the grill guard to the headlights. The holes are slotted so the grill guard can be raised or lowered. It also can be leaned forwards or back. Then tighten carriage bolts.

MAKE SURE ALL NUTS AND BOLTS ARE TIGHT!

----- WARNING -----

Special care should be exercised in the handling, storage and installation of Ranch Hand equipment.

The actual weight of each piece of equipment will vary depending on style and model. The weight of the equipment is sufficient in volume to warrant special care, assistance and in some instances, the use of mechanical equipment during the transfer and installation of the equipment. Do not assume a position directly under the equipment during installation. Be sure the equipment has been connected and stabilized during installation to prevent falling or shifting of positions.

Periodically check tightness of bolts to make sure they are tight, and unlikely to fail.

Rev. 2021