

KITCHEN AND BATH

Purpose

This document outlines the procedure to winterize an RV faucet to prevent damage to the faucet.

Safety

WARNING

The "WARNING" symbol above is a sign that a procedure has a safety risk involved and may cause death or serious personal injury if not performed safely and within the parameters set forth in this manual.

WARNING

Do NOT use automotive antifreeze to winterize potable water systems. Such solutions are highly toxic. Ingestion may cause serious injury or death. Use only propylene glycol-based antifreeze specified for RV winterization. Follow all product safety precautions to avoid personal injury or damage to the unit.

Procedure

1. Open all water valves in the unit.
2. Use a pressurized hose to run RV-specific antifreeze through the faucet system.

NOTE: To be effective, the antifreeze must run through the entire faucet system until it flows from the faucet.

3. Run antifreeze on cold side until all water is removed from lines and only antifreeze is coming from faucets.
4. Run antifreeze on hot side until all water is removed from lines and only antifreeze is coming from faucets.
5. Close all water valves in unit.
6. Cover faucet tip with plastic to ensure antifreeze does not drip from faucet.