




STEPS

NOTE: Part numbers are shown for identification purposes only. Not all parts are available for individual sale. All parts with a link to the Lippert Store can be purchased.




Callout	Part #	Description
A	3691461	Single Retractable Step
B	3756271	30" Single Step with Extended Throw
C	233509	Single Retractable Step (3" Spacers) (OBSOLETE)
	233703	Single Retractable Step (4" Spacers)
D	372261	Double Retractable Step Kit
	128980	Double Retractable Step Kit (OBSOLETE)
E	168367	29" Double Retractable Step
F	3658373	Triple Retractable Step

STEPS




Callout	Part #	Description
G	165046	26" Slide Step (OBSOLETE)
H	165049	30" Slide Step (OBSOLETE)
	431585	30" Slide Step

STEPS




Callout	Part #	Description
I	301695	Coachstep® Motor
J	301702	Coachstep® Module
K	301692	Coachstep® Pigtail Wire Harness
L	162986	Drive Shaft 25.75" (OBSOLETE)
M	301696	Single/Double Gear Plate Assembly
N	164348	Triple Gear Plate Assembly
NOTE: If you have this gear plate on your Coachstep and it is damaged, you will need to replace the entire step assembly.		
O	165983	Slide Step Gear Plate Assembly
P	163001	Left Hand First Step Drive Arm (OBSOLETE)
Q	163002	Right Hand First Step Drive Arm (OBSOLETE)
R	163500	Left Hand Double Step Drive Arm (OBSOLETE)
S	163502	Right Hand Double Step Drive Arm (OBSOLETE)

STEPS



Callout	Part #	Description
T	165221	Anti-Skid Tape (25" x 8")
U	165667	Top Step Link Plate
V	165959	Bottom Step Link Plate
W	166187	Step Slide Rail 12" (OBSOLETE)
	166186	Step Slide Rail 22"
X	165910	Top Step 26"
	171812	Top Step 30"
Y	165880	Bottom Step 26"
	171811	Bottom Step 30"
Z	165048	Step Light (OBSOLETE)
	358693	Step Light

STEPS



Callout	Part #	Description
AA	216567	Wet Bolt Replacement Kit
AB	165218	Washer, .875 O.D. x .410 I.D. x .015
AC	116531	Bronze Bushing
AD	128952	Bolt; 5/16" - 18 x 1 1/4"
AE	181440	Nut; 5/16" - 18