

## Jackknife Sofa



Assembly Guide





## **A CAUTION**

## MOVING PARTS CAN PINCH. CRUSH OR CUT. KEEP CLEAR AND USE CAUTION.

## Assembly

NOTE: The leg brackets in steps 1-4 are an optional kit, PN 364582. Skip to step 5 if no leg bracket kit.

Remove sofa from packaging.

1. Turn over the sofa and lay it flat on a protective surface with the back facing upward (Fig.1).

2. Align the holes in the leg brackets with the corresponding holes in the frame (Fig.2). The leg brackets can be used on either side of the sofa, in either orientation.




Fig.1




**3.** Insert the ¾" bolts through the bottom of the frame and through the leg bracket and attach the washer and nylon nut from the top **(Fig.2&3)**.

**4.** Using either a ½" socket, open-end, box or adjustable wrench from both above and below, tighten (**Fig.3**).

NOTE: Do not over-tighten.


5. Turn sofa upright to attach front kick panel.

**6.** Raise the front of the sofa to view the front of the frame bar where the kick panel will be positioned (**Fig.4**).





7. Hook the kick panel over the front frame bar and center (Fig.5). Lower the front of the sofa back in place.



Manual information may be distributed as a complete document only, unless Lippert provides explicit consent to distribute individual parts.

All manual information is subject to change without notice. Revised editions will be available for free download at <u>lippert.com</u>. Manual information is considered factual until made obsolete by a revised version.

Please recycle all obsolete materials and contact Lippert with concerns or questions.

