

# **ONECONTROL® CONNECTANYWHERE™ WITH VOICE**

### **ELECTRONICS**

### Introduction

OneControl® ConnectAnywhere™ can now be controlled with simple voice commands.

With OneControl's Voice command system, the Echo Dot, powered by Amazon Alexa voice assistant, can be taken along to not only control the coach via voice, but maintain the convenience of a smart home on the road.

A registered ConnectAnywhere system, comprised of one or more LCI OneControl-compatible Controller Area Network (CAN) controllers, a data package and Internet access are required.

## Pair the ConnectAnywhere System with the Alexa App

The Alexa app is needed to complete the linking process to the ConnectAnywhere system.

Amazon app compatibility:

- Fire OS 3.0 or higher
- Android 5.0 or higher
- iOS 9.0 or higher

Download the free Alexa app from amazon® appstore, Google play™, or Apple App Store®.

- **1.** From a mobile device, go to one of the designated app stores.
- **2.** Search for "Alexa app."

**NOTE:** The Alexa app downloads automatically to Alexa-enabled Fire tablets. To learn how to use the app, go to Amazon Alexa App Basics.

- 3. Launch the Alexa app and create an account.
- **4.** Set up the new device.
- **5.** Choose a device.
- **6.** Connect to Wi-Fi.
- **7.** Follow the on-screen prompts.
- **8.** Search for, and enable, the LCI OneControl skill.
- **9.** Link the Amazon account to the LCI account by following the on-screen prompts.

The OneControl login page is: <a href="lci1.com/onecontrol-login">lci1.com/onecontrol-login</a>.

**NOTE:** After the Amazon Alexa account is linked to the ConnectAnywhere account, Alexa can be used to control the coach's OneControl-compatible controllers by voice.



Amazon®, Echo Dot, Alexa, Fire and all related logos are trademarks of Amazon.com, Inc. or its affiliates.



App Store<sup>®</sup> is a trademark of Apple Inc.



Android™ and Google Play™ are trademarks of Google LLC.

# ONECONTROL® CONNECTANYWHERE™ WITH VOICE

### **ELECTRONICS**

# **Controlling ConnectAnywhere by Voice**

Controlling CAN devices by voice with the Alexa assistant through the Amazon Echo Dot **MUST** be done by issuing an invocation phrase followed by a request phrase.

## Sample Alexa Voice Commands

The following are some examples of invocation and request phrases.

### Example invocation phrases:

- "Alexa, ask OneControl to..."
- "Alexa, tell OneControl to..."
- "Echo, ask OneControl to..."
- "Echo, ask OneControl for..."

### Example request phrases:

- "...turn all the lights on."
- "...turn on the kitchen lights."
- "...dim lights."
- "...turn all lights bright."
- "...dim kitchen lights to 10%."
- "...turn on all cooling to 70 degrees."
- "...set the temperature in zone 1 to 68 degrees."

#### **Control Connected Devices**

Learn the basics and how to interact with connected devices.

Control any LCI OneControl-enabled function installed by the RV's manufacturer. Control anything ranging from vital functions like tank levels to entertainment lighting.



As a supplier of components to the RV industry, safety, education and customer satisfaction are our primary concerns. Should you have any questions, please do not hesitate to contact us at (574) 537-8900 or by email at <a href="mailto:customerservice@lci1.com">customerservice@lci1.com</a>. Self-help tips, technical documents, product videos and a training class schedule are available at <a href="mailto:lci1.com">lci1.com</a> or by downloading the MyLCI app.