
ELECTRIC LANDING GEAR SWITCH HARNESS

TI-069

LEVELING AND STABILIZATION

Fig. 1 ELG Switch Wiring Diagram



NOTE: When working with Electric Landing Gear Switch Harnesses, the fuse holder (with fuse installed) must be included in the return. Do not remove harness without the fuse holder attached as it will void the warranty and prevent receiving compensation for a warranty claim.

NOTE: Do not remove fuse from ELG Switch Harnesses before installing units.

As a supplier of a broad array of highly-engineered components in the recreation and transportation product markets, safety, education and customer satisfaction are our primary concerns. Should you have any questions, please do not hesitate to contact us at 432-LIPPERT (432-547-7378) or by email at customerservice@lci1.com. Self-help tips, technical documents, product videos and a training class schedule are available at lippert.com or by downloading the LippertNOW app.