

INTERIORS

Purpose

This document provides instructions on replacing a damaged parachute pull release.

Safety

Read and understand all instructions and adhere to safety labels before beginning any component replacement.

CAUTION

Always wear eye protection when performing this installation procedure. Other safety equipment to consider would be gloves and possibly a full face shield, depending on the nature of the installation procedure.

WARNING

The “WARNING” symbol above is a sign that an installation procedure has a safety risk involved and may cause death or serious injury if not performed safely and within the parameters set forth in this manual.

Procedure

1. Remove the backrest.
 - A. Pull outward on the spring clip (Fig. 1) that is attached to the backrest structure. Lift up to remove the backrest from the chair.

Fig. 1



- B. Place the chair on the ground (Fig. 2) arm-side down. Release the footrest.

Fig. 2




INTERIORS

2. Remove the wood screws (Fig. 3A) that secures the armrest to the side of the seat frame (Fig. 3B).


NOTE: Mechanisms after the year 2016 are attached to the armrest directly.

Fig. 3



3. Look for any wood screws hidden under the mechanism. To do this, remove the mechanism by removing the four wood screws (Fig. 4A) around the perimeter of the mechanism (Fig. 4A).


Fig. 4



4. Refer to figure 5 for the following:
- A. The parachute handle on the seat frame on the side that was against the arm.
 - B. Put the parachute 6" from the front edge of the seat cushion.
 - C. Make sure the parachute screw plate is near the top edge of the seat's wooden framework.

NOTE: Green lines indicate the designated area.


Fig. 5



INTERIORS

NOTE: Mechanisms after the year 2016 are attached to the armrest and have a designated location for the parachute screw plate on the armrest (Fig. 6).


Fig. 6



5. Remove old cable from mechanism (Fig. 7).

NOTE: It may be necessary to break the parachute cable clip that is snapped in to the mechanism.

Fig. 7



6. Secure the new parachute cable clip in the mechanism slot and insert the "S" into the lower hole of the mechanism actuator.
7. Secure the recliner mechanism to the seat structure.
8. Utilizing the same holes, secure the seat frame and mechanism onto the arm structure with the previously removed wood screws.
 - A. Make sure not to overtighten the screws and strip out the holes.
 - B. Make sure the seat's wooden frame meets the armrest wood at the lower corner of the armrest structure.
 - C. Make sure the footrest is even with the front lower corner of the armrest structure.

As a supplier of components to the RV industry, safety, education and customer satisfaction are our primary concerns. Should you have any questions, please do not hesitate to contact us at (574) 537-8900 or by email at customerservice@lci1.com. Self-help tips, technical documents, product videos and a training class schedule are available at lci1.com or by downloading the MyLCI app.